


* 2 : w/o Stereo Component Amplifier



TVIP System

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A2	32 (1ZZ-FE)	D8	40 (*2)	J7	37
C8	36	D9	38 (*1)	J10	38 (*1)
D2	36		40 (*2)		40 (*2)
D4	38 (*1)	G3	37	L4	38 (*1)
	40 (*2)	H6	32 (1ZZ-FE)		40 (*2)
D5	38 (*1)		34 (2ZZ-GE)	S3	33 (1ZZ-FE)
	40 (*2)	I10	37		35 (2ZZ-GE)
D6	38 (*1)	I11	A	S4	A
	40 (*2)	I13	38 (*1)	S8	37
D7	38 (*1)		40 (*2)	T2	37
	40 (*2)	J2	37	T3	37
D8	38 (*1)	J6	37	U1	37

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
IK		
IL	24	
IM		
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)
3A	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4A	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IA4		
IA5		
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC2		
ID2	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
II1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
II2		
IJ1	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IJ3		
IL3	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)

* 1 : w/ Side Airbag and/or Stereo Component Amplifier * 2 : w/o Side Airbag and Stereo Component Amplifier



: Ground Points

Code	See Page	Ground Points Location
IE	44	Behind the Combination Meter
IG	44	Right Kick Panel